

# Counters

## General

This part is used to load all counters in MXSuite. The sheet in the Excel file is called "Counters".

## Details fields

To fill the Excel file correctly, make sure that all fields are filled correctly. Below are the fields listed.

Field	MAX Characters	Required	Comment
Name	128	X	Name of the Counter
Unit	128	X	The unit name should exactly match the <u>name</u> of the Unit as known in Administration -> Units
AveragePerWeek		X	The maximum average per week for the selected unit. For unit Running hours, the average must be set to 168
ActualCounterValue		X	The actual counter value for the imported counter machine
ParentCounter			If the counter will use the input from another counter, specify here the countername

## Example

	A	B	C	D	E
1	Name	Unit	AveragePerWeek	ActualCounterValue	ParentCounter
3	Main Engine SB	Runninghours	168	3000	
4	Gearbox SB	Runninghours	168	2500	Main Engine SB

Revision #2

Created 2025-05-08 13:28:07 UTC by Theo Vlot

Updated 2025-05-08 13:38:00 UTC by Theo Vlot