

Counters

General

This part is used to load all counters in MXSuite. The sheet in the Excel file is called “Counters”.

Details fields

To fill the Excel file correctly, make sure that all fields are filled correctly. Below are the fields listed.

Field	MAX Characters	Required	Comment
Name	128	X	Name of the Counter
Unit	128	X	The unit name should exactly match the <u>name</u> of the Unit as known in Administration -> Units
AveragePerWeek		X	The maximum average per week for the selected unit. For unit Running hours, the average must be set to 168
ActualCounterValue		X	The actual counter value for the imported counter machine
ParentCounter			If the counter will use the input from another counter, specify here the countername

Example

	A	B	C	D	E
1	Name	Unit	AveragePerWeek	ActualCounterValue	ParentCounter
3	Main Engine SB	Runninghours	168	3000	
4	Gearbox SB	Runninghours	168	2500	Main Engine SB